

TOOLS REQUIRED FOR THE CORRECT ASSEMBLY OF HISPAPLANO LARGE SIZE CLAY BRICKS



Pallet Trolley

To carry the pallets to the work location



Screeds

Have to be placed previously 70 cm. from each other.



Electric Blender and Rubber basket

Used to prepare de Mortar



Trowel

Used both to apply the Mortar in the tongued edge of the brick and to spread the it in the wall surface to stick the Drywall Boards (Hispalam)



Screw Jacks

Used both to guaranty the wall stability during the drying process of the mortar and to secure the doorframes.



Guillotine

For and accurate and easy cut of the clay bricks.



Scraper

Used to remove the excess of mortar.